

## PowerLite Home Cinema 720

<b><u>DESCRIPTION</u></b>	<b><u>PART NUMBER</u></b>
Remote Control (pearl-white)	144 6096
Power Cable (black) - 3 prong est. 10'	208 0118
Lamp (V13H010L39)	145 1739
Lens Cap	144 6026
	144 6026

Order user replaceable parts from an [Epson authorized parts distributor](http://www.epson.com/cgi-bin/Store/AboutEpsonConnection.jsp).

<http://www.epson.com/cgi-bin/Store/AboutEpsonConnection.jsp>

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts  
by using the “Help me find...” tool in the right column of the

[Epson Support](http://www.epson.com/cgi-bin/Store/support/SupportIndex.jsp) home page.

<http://www.epson.com/cgi-bin/Store/support/SupportIndex.jsp>